
ASSEMBLE WITH BILT



To assemble your griddle, we recommend scanning and using the BILT App or following along with our assembly video.



 \bigcirc



2/7/24 2:53 PM

GETTING STARTED




To get started with your griddle download the Current App



FOR BEST RESULTS

A 20 amp breaker and 20 amp GFCI outlet is recommended. For best performance and to prevent tripping, do not plug other appliances or devices into the same circuit as your Current.

KNOW YOUR CONTROLS



Power Button

Turns unit on and off. Short press turns on, 2 second hold to turn off.

Main Control Knob Controls temperature and timer. Spin left or right to adjust, press in to confirm.

Status Indicator Light Ring *Communicates grill status. See Indicator Guide on the next page.*

QUICK START GUIDE

Timer Icon Short press turns on the timer section and

switches command of the Main Control Knob

2 second press and hold initiates the Auto Seasoning program.

First Use Before using the griddle, you must season the cooking surface. To do this, pick a high smoke-point oil of your choice, we recommend canola or vegetable oil. Apply a small amount to the griddle surface, and wipe evenly across the surface. Next, power on the griddle by pressing the power button, then press and hold the Auto Season button, then press in the Main Control Knob to confirm. This will start the seasoning process. You may repeat this process until the seasoning is even and to your liking.

CONTROL GUIDES



Temperature Range Guide

LOW	200°F-400°F
MEDIUM	400°F-500°F
HIGH	500°F+

Caring for your Current



Scan the QR code to register your product, double your warranty and learn tips and tricks to maintain your Current griddle.